



FASTENING GRILLES WITH BACKER TO WALL

- ATTACH FURRING STRIP (BY OTHERS) TO WALL STUDS. (1 AT EVERY SEAM) AND PAINT BLACK

-DRILL PILOT HOLE THROUGH BACKER THEN SCREW THROUGH BACKER INTO FURRING STRIP.

These drawings show typical conditions in which the Armstrong product depicted is installed. They are not a substitute for an architect's or engineer's plan and do not reflect the unique requirements of local building codes, laws, statutes, ordinances, rules and regulations (Legal Requirements) that may be applicable for a particular installation.

Armstrong does not warrant, and assumes no liability for the accuracy or completeness of the drawings for a particular installation or their fitness for a particular purpose. The user is advised to consult with a duly licensed architect or engineer in the particular locale of the installation to assure compliance with all Legal Requirements.

Armstrong is not licensed to provide professional architecture or engineering design services.

PROJECT NAME: TRANSITIONS WOODWORKS GRILLE - BACKER ATTACHING TO WALL

DWG. NO. DETAIL	PATH:	REV: .	DATE: .
DATE: 12/16/13	SCALE:	DESC.: .	
DRAWN BY: MSS	CHK BY:	.	



CEILING SYSTEMS * ARMSTRONG WORLD INDUSTRIES, INC. * Lancaster, PA * Phone: 877-ARMSTRONG