

NOTES:


- WOODWORK GRILLE FORTÉ TORSION SPRING ACCESS 1. DOORS ARE TO BE INSTALLED USING THIS ORDER OF OPERATIONS
- 2. ACCESS DOORS CAN BE INSTALLED WITHIN THE LIMITATIONS LISTED BELOW
- 3. CAREFULLY CONSIDER THE LOCATION OF ACCESS DOORS IN RELATION TO GRID BUILD. TORSION SPRINGS CAN INTERFERE WITH GRID MEMBERS IF PANEL-TO-GRID CONSIDERATION IS NOT PLANNED

LIMITATIONS:

- 2 CONSECUTIVE ACCESS DOOR PANELS CAN BE INSTALLED • IN THE 1ft PANEL DIRECTION
- THERE IS NO LIMITATION FOR CONSECUTIVE ACCESS ٠ DOOR PANELS IN THE PANEL LENGTH DIRECTION
- CONSECUTIVE ACCESS DOOR SECTIONS MUST BE FULL ٠ UNTRIMMED PANELS SURROUNDED BY DIRECT ATTACHED PANELS ON ALL SIDES
- 1 DIRECT ATTACHED PANEL MUST BE BETWEEN A NEW ACCESS DOOR SECTION IN THE 1ft PANEL DIRECTION
- PERIMETER PANELS CANNOT BE ACCESS DOOR PANELS •







ns which the Armstrong products depicted are installed. They are not a substitute for an architect's or engineer's plan and do not reflect the unique requirements of local building codes, laws, statutes, ordinances, rules and regulations (Legal Requirements) that may be applicable for a particular installation. Armstrong does not warrant, and assumes no liability for the accuracy or completeness of the drawings for a particular installation or their fitness for a particular purpose. The user is advised to consult with a duly licensed architect or engineer in the particular locale of the installation to assure compliance with all legal requirements. Armstrong is not licensed to provide professional architecture or engineering design services.