

NOTES:


1. WOODWORK GRILLE FORTÉ TORSION SPRING ACCESS DOOR
SAFETY CABLES ARE OPTIONAL AND INSTALL USING THIS
ORDER OF OPERATIONS
2. REFER TO STANDARD INSTRUCTIONS AND DETAILS FOR
WOODWORKS GRILLE FORTÉ TORSION SPRING ACCESS DOOR
INSTALLATION. THESE DETAILS ARE USED SUPPLEMENTARY TO
STANDARD INSTALLATION.

1) ATTACH A 6"-8" PIECE OF PRELUDE MAIN BEAM OR PRELUDE HEAVY DUTY CROSS TEE TO THE LAST NOTCHED
BACKER ON EACH END OF ACCESS DOOR.


- USE 2x #6 X 1-5/8" SCREWS FOR SLATS UNDER 3" WITH SOLID WOOD GRILLES AND ALL VENEERED
GRILLES
- USE 2x #8 X 2-1/2" SCREWS FOR SLATS OVER 3" WITH SOLID WOOD GRILLES
- PRE-DRILL AN 1/8" HOLE THROUGH THE NOTCHED BACKERS BEFORE DRIVING THE FASTENER FROM
BELOW, THROUGH THE BACKER INTO THE GRID
- 2 FASTENERS ARE REQUIRED PER GRID SECTION
- IF NO HANGER HOLES ARE PRESENT, DRILL A NEW Ø.25" HOLE TO ATTACH THE SAFETY CABLE TO

2) ATTACH SAFETY CABLE TO PANEL AND AFFIX TO SUSPENSION SYSTEM


- PASS SAFETY CABLE UNDER NEAREST CROSS TEE THAT RUNS PARALLEL TO ACCESS DOOR
- BRING CABLE UP AND AROUND CROSS TEE AND PASS THE END WITH THE CLIP THROUGH THE LOOP
- ATTACH CLIP TO ANY HANGER HOLE ON SECTION OF GRID FASTENED TO ACCESS DOOR



#6 X 1-5/8" (BY OTHERS)
#8 X 2-1/2" (BY OTHERS)
SEE ABOVE



DETAIL A



DETAIL A
SCALE 1 / 4

Armstrong
CEILING & WALL SOLUTIONS

WOODWORKS GRILLE FORTÉ TORSION SPRING ACCESS DOOR
SAFETY CABLE INSTALLATION

DRAWN BY: APF DATE: 11/1/2022 PD

These drawings show typical conditions which the Armstrong products depicted are installed. They are not a substitute for an architect's or engineer's plan and do not reflect the unique requirements of local building codes, laws, statutes, ordinances, rules and regulations (Legal Requirements) that may be applicable for a particular installation. Armstrong does not warrant, and assumes no liability for the accuracy or completeness of the drawings for a particular installation or their fitness for a particular purpose. The user is advised to consult with a duly licensed architect or engineer in the particular locale of the installation to assure compliance with all legal requirements. Armstrong is not licensed to provide professional architecture or engineering design services.